




2701433 Rev.04

Installation / Installation / Installazione / Instalación / Installation / Instalacja

FR Thermostat radio pour commande de chauffage
EN Radio thermostat for heating control
ES Termostato digital radio para calefacción
IT Termostato radio per comando di riscaldamento
DE Funkthermostat zur Heizungssteuerung
PL Termostat radiowy do sterowania ogrzewaniem



Association / Association / Asociación / Associazione / Verbindung / Przypisanie


> 3s Temps d'appui / Press time / Tiempo de pulsación / Tempo pressione / Tastendruckdauer / Czas naciskania

Clignotement lent / Slow flashing / Parpadeo lento / Lamppeggiamento lento / Langsames blinken / Wolne miganie


Voyant éteint / LED off / Testigo apagado / Spia spenta / Kontrolleuchte aus / Lamka gaśnie

	2 x 1,5V LR03 - AAA Alkaline
	X2D : [868 – 868.6] MHz
°C	-5°C / +40°C
	80 x 80 x 23 mm
	IP 30


Association / Association / Asociación / Associazione / Verbindung / Przypisanie



Configuration / Configuration / Configurazione / Configuraciones / Konfiguration / Konfiguracja



Utilisation / Use / Utilización / Utilizzo / Bedienung Sposób użycia



⌚ Confort, Comfort, Conforto, Comfort, Komfort, Komfort
⌚ Economie, Set-back, Economía, Risparmio, Sparbetrieb, Oszczędny
⌘ Hors-gel, Frost-protection, Anti-helada, Antigelo, Frostschutz, Zamarzaniu

Changement des piles / Changing the batteries Sostituzione delle pile / Cambiar las pilas Batterien ersetzen / Zmiana baterii

